



GN 1/1 rolltop cover



	L x W	H	GN	Color
APS 11018	20 ⁷ / ₈ x 12 ⁷ / ₈	7 ¹ / ₂	1/1	Clear



APS 11022
GN 1/2

GN cover with opening



Clear with chrome handle and opening for easy self-serving.

	D	H	GN		Color
APS 11022	13 ³ / ₄ x 10 ⁷ / ₈	6 ³ / ₄	1/2	one long side cut out	Clear
APS 11027	21 ³ / ₈ x 13 ³ / ₄	8 ¹ / ₈	1/1	one long side cut out	Clear
APS 11028	21 ³ / ₈ x 13 ³ / ₄	8 ¹ / ₈	1/1	one small side cut out	Clear



APS 11027
GN 1/1



APS 11028
GN 1/1



APS 11305
GN 1/1 cover

APS 11300
tray

GN 1/1 locking cover

HOCHSTAPLER



Clear plastic tray locks into the cover to avoid slipping off.

	L x W	H	GN	Color
APS 11305	21 ¹ / ₈ x 13	3 ⁵ / ₈	1/1	Transparent



Covers stack to save space and make transportation more convenient.

COVER



Find compatible serving pieces on pages 62-63.