

Non-slip tip

Prevents tool from sliding into pots.

Su punta antideslizante

Evita que el utensilio se deslice dentro de la olla



Fiberglass Turner
Espátula de fibra de vidrio

ITEM #	DIM
7112302	11.25" / 28.6 cm



Fiberglass Wide Turner
Espátula ancha de fibra de vidrio

ITEM #	DIM
7112322	11.25" / 28.6 cm



Fiberglass Spaghetti Server
Servidor de espaguetis de fibra de vidrio

ITEM #	DIM
7112312	12" / 30.5 cm



Fiberglass Slotted Spoon
Cuchara ranurada de fibra de vidrio

ITEM #	DIM
7112308	11.75" / 29.8 cm



Fiberglass Serving Ladle
Cucharón para servir de fibra de vidrio

ITEM #	DIM
7112324	12" / 30 cm



Fiberglass Basting Spoon
Cuchara para hilvanar de fibra de vidrio

ITEM #	DIM
7112303	11.75" / 29.8 cm