



White

- MCW61** Oval Casserole, 5 oz. (147.9 mL)
4 $\frac{3}{4}$ " L x 3" W x 1 $\frac{1}{4}$ " H
6" L with Handles
(12.1 x 7.6 x 3.2, 15.2 cm)
- MCW41** Round Casserole, 6 oz. (177.4 mL)
4 $\frac{3}{8}$ " Dia. x 1 $\frac{1}{4}$ " H
6" L with Handles
(11.1 x 3.2, 15.2 cm)
- MFPW41** Fry Pan, 6 oz. (177.4 mL)
4 $\frac{3}{8}$ " Dia. x 1 $\frac{1}{4}$ " H
6 $\frac{1}{4}$ " L with Handle
(12.1 x 3.2, 15.9 cm)
- MCRW72** Round Casserole, 39 oz. (1.2 L)
7 $\frac{5}{8}$ " Dia. x 2 $\frac{3}{8}$ " H
9 $\frac{7}{8}$ " L with Handles
(19.4 x 6, 25.1 cm)
- MCW81** Oval Casserole, 13 oz. (384.5 mL)
8 $\frac{1}{4}$ " L x 5 $\frac{1}{2}$ " W x 1 $\frac{1}{2}$ " H
10 $\frac{3}{8}$ " L with Handles
(21 x 14 x 3.4, 26.4 cm)
- MFPW81** Fry Pan, 24 oz. (709.8 mL)
8 $\frac{1}{2}$ " Dia. x 1 $\frac{1}{4}$ " H
12" L with Handle
(21.6 x 3.2, 30.5 cm)
- MBW93** Round Bowl, 82 oz. (2.4 L)
9 $\frac{3}{4}$ " Dia. x 3 $\frac{1}{4}$ " H
12 $\frac{1}{2}$ " L with Handles
(24.8 x 8.3, 31.8 cm)

